

# SOS4 FILTERGRAM ANALYSIS



**Samples submitted for analysis must be supplied in a Filtergram kit (Part Number SOS4).**

- ➔ Collect **Oil sample** as per recommended sampling method into **YELLOW** lidded bottle with **RED** lidded container.  
*Kit includes Oil + Filter analysis*
- ➔ Ensure work bench is free from contamination, using filter cutter (Part no: 175-7546), remove filter cartridge from canister.
- ➔ Collect approximately 10cm<sup>2</sup> of filter pleat, squeeze out oil and place into provided **SOS4** re-sealable plastic bag.  
  
**\* Note – Filter sample MUST be in the SOS4 bag.**
- ➔ Complete registration card and ensure card is supplied in box with both oil and filter sample.
- ➔ Place box containing the oil & filter samples into provided prepaid mailing satchel and send to laboratory.



**Condition Monitoring Centre**  
Fluid Analysis Laboratory

**Hastings Deering**

