



SOS4 FILTERGRAM ANALYSIS

- Ensure workbench is free from contamination.
- Cut filter using the 175-7546 filter cutter.
- Place approximately 10cm² of filter pleat into supplied plastic re-sealable bag.
- Place filter medium and completed sample label into the supplied SOS4 box then into the pre-paid Australia Post mail satchel.
- Complete customer name, jobsite and sign the Dangerous Goods declaration.

Manual particle counting or oil only filtergrams.

Collect sample using the standard SOS3 (white lid) sample bottle and place the sample in the SOS4 box.

Ensure the sample card is clearly marked to indicate the required analysis.

